



tesstools.net

Part List

Item	Description	Part No.
1	Transformer	611007
2	Rectifier	610364
3	Load Switch	610263
4	Volt meter	611018
5	Charge Rate Switch	605675
6	Timer	610895
7	Ammeter	611008
8	Front panel	611009
9	Fan blade	610189
10	Fan motor	610190
11	Load assembly	611010
12	DC circuit breaker	610536
13	Back panel	610561
14	Right side panel	611032
15	Top panel	611011
16	Base panel	610054

Parts not shown

AC power cord	610696
Positive DC cable	611012
Negative DC cable	611013
Left side panel	611031
Jaw kit (repairs 1 jaw)	610970
Clamps (1 pair w/jaws)	6202
Front Leg	605671
Axle w/nuts	610052
Wheel w/Nuts (2)	605672
Handle	605213

